



www.prolinestoneveneer.com



W172 N13050 Division Road
Germantown, WI 53022

(262) 677-1919

(262 677-9065 Fax)

PRO-LINE Tech Bulletin 3900-03

WATER REPELLENT COATING (with no change in color or finish)

For water repellency, apply Prosoco, Siloxane PD (water-based, ready to use) or Prosoco, Siloxane WB (water-based, 1:9 concentrate with water) or Prosoco, Custom Masonry Sealer. ("Or equal" products are acceptable. This bulletin is based on product testing as footnoted.)

Test the following procedure first on a small area before general application to insure the desired result.

1. When applying with low pressure spray (20 psi):

Apply enough material in a saturating application from the bottom up creating a 4' to 8" rundown below the spray point. Let the application penetrate (2-3 min. for WB and Custom Masonry Sealer, 5-10 min. for PD) then re-apply. Less material will be needed for the second application.

2. When using a brush or roller:

Apply enough material to saturate the surface. Let application penetrate (2-3 min. for WB and Custom Sealer, 5-10 min. for PD). Brush out heavy runs and drips.

Read all manufacturer's instructions for full descriptions on use, preparation, application, safety information and technical support before starting the application.

*Per PROSOCO, INC., test report, "PROLINE STONE, Project No. 0305-04 (revised)".